



## EXPLODED VIEW AND PARTS LIST — UNIT




| Item | Part #    | Description                   | Item | Part #   | Description              |
|------|-----------|-------------------------------|------|----------|--------------------------|
| 1    | 192772GS  | BASE                          | 10   | 192199GS | EXTENSION                |
| 2    | B191874GS | HANDLE                        | 11   | 192128GS | KIT, Hook                |
| 3    | 194377GS  | BILLBOARD                     | 12   | B3263GS  | GUN                      |
| 4    | 185877GS  | HOSE                          | 13   | B2203GS  | KIT, Handle Connector    |
| 5    | 192318GS  | KIT, Engine Mounting Hardware | 14   | 192310GS | KIT, Vibration Mount     |
| 6    | 192131GS  | KIT, Pump Mounting Hardware   | 15   | 192317GS | KIT, Wheel               |
| 7    | 192309GS  | KIT, Hook                     | 16   | 23139DGS | KEY                      |
| 8    | 191265GS  | KIT, E-Ring                   | 17   | 194106GS | ASSY, Pump (see page 17) |
| 9    | B5646GS   | KIT, Spray Tip                | 900  | NSP      | ENGINE                   |

### Items Not Illustrated

| Part #    | Description     |
|-----------|-----------------|
| 194445GS  | MANUAL, Owner's |
| MS5242    | MANUAL, Engine  |
| 194482GS  | KIT, Decals     |
| BB3061BGS | OIL, Engine     |



## EXPLODED VIEW AND PARTS LIST — PUMP



| Item | Part #   | Description            |
|------|----------|------------------------|
| 19   | 190571GS | CAP, Oil               |
| 28   | 190673GS | MANIFOLD               |
| 45   | 190578GS | PIN                    |
| 62   | 190581GS | CAP                    |
| 76   | 194298GS | THERMAL RELIEF         |
| 77   | 190585GS | OIL BOTTLE (not shown) |
| A    | 190594GS | KIT, UNLOADER          |
| B    | 190670GS | KIT, WATER INLET       |
| C    | 190669GS | KIT, BREATHER TUBE     |
| D    | 193808GS | KIT, HEAD BRASS        |

| Item | Part #   | Description             |
|------|----------|-------------------------|
| E    | 193806GS | KIT, CHECK VALVES       |
| F    | 190592GS | KIT, INLET CHECK        |
| G    | 190593GS | KIT, CHEMICAL INJECTION |
| H    | 193807GS | KIT, SEAL SET           |
| J    | 189971GS | KIT, CHEMICAL HOSE      |
| K    | 193971GS | KIT, PIPE FITTING       |
| L    | 193972GS | KIT, UNLOADER SEAT      |

**NOTE:** Item letters A - L are service kits and include all parts shown within the box.