


LAWN AERATOR MODEL NO. 45-01661



REPAIR PARTS LIST FOR LAWN AERATOR, MODEL 45-01661

REF. NO.	PART NO.	QTY.	DESCRIPTION	REF. NO.	PART NO.	QTY.	DESCRIPTION
1	23229	2	Frame Angle (Long)	25	23978	1	Brace, Hitch
2	62096	3	Spool Assembly	26	23981	2	Bracket, Hitch
3	23084	18	Knife, Aerator	27	62978	1	Upper Axle Frame Assembly
4	43182	36	Bolt, Hex 5/16" x 3/4" Lg.	28	62442	1	Ass'y.; Axle Lock (wheel lift)
5	43086	36	Lock Washer Spring 5/16" ID	29	23458	1	Tube, Lift Handle
6	43064	36	Nut, Hex Lock 5/16-18 Thd.	30	43756	2	Wheel Ass'y Comp. 14 x 4
7	23992	1	Shaft	31	43362	1	Grip, Handle
8	43023	3	Pin, Clevis 3/8" Dia. x 2" Lg.	32	43840	1	Bolt, Hex 5/16-18 x 1-1/4" Lg.
9	43055	3	Hairpin Cotter 3/32"	33	43064	1	Nut, Hex Lock 5/16-18 Thd.
10	43001	11	Bolt, Hex 3/8-16 x 1" Lg.	34	23519	3	Spacer 13/32 ID x 9/16" OD x 11/32" Lg.
11	43003	28	Lock Washer, Spring 3/8" ID				
12	43082	28	Nut, Hex Lock 3/8-16 Thd.	35	43754	4	Washer, Flat 21/32 x 1-5/8 x 16 Ga.
13	43012	6	Bolt, Hex 1/4-20 x 3/4" Lg. (Grade 5)	36	43010	2	Pin Cotter 1/8 x 1" Lg.
14	43177	6	Lock Washer, Spring 1/4" ID	37	23520	2	Spacer, 1-1/2" OD x 5/8" ID x 7/32"
15	43013	6	Nut, Hex Lock 1/4-20 Thd.				
16	736-0259	2	Washer, Flat 1" x 2"	38	43070	4	Washer, Flat 3/8" Std.
17	43488	2	Spring Pin 3/16" x 1-5/8" Lg.	39	23537	1	Spacer, 13/32 ID x 9/16" OD x 19/32" Lg.
18	43087	2	Bolt, Hex 3/8-16 x 1-1/4" Lg.				
19	46069	2	Bearing	40	43350	10	Bolt, Carriage 3/8-16 x 1" Lg.
20	43088	6	Washer, 1/4" Std.	41	43062	2	Bolt, Hex 3/8-16 x 1-1/2 Lg. (Grade 5)
21	23494	2	Bracket, Frame Side				
22	23977	2	Yoke, Hitch Mount	42	43432	2	Bolt, Hex 3/8-16 x 2-1/2" Lg.
23	23980	1	Axle Bracket (Lower)	43	23976	2	Frame Angle (Short)
24	23454	1	Axle	44	710-0305	1	Bolt, Carriage 3/8" x 1-1/4"
					46070	1	Owners Manual

* Purchase Common Hardware Locally