



PARTS LIST FOR MODEL 11-2197

Ref. No.	Part No.	Description	Ref. No.	Part No.	Description
1	19-141	Nut - Lock 10-24	61	20-146	Screw - 3/8-16 x 1/2
2	47-595	Cable - Clutch	62	43-392	Support Pulley Assembly
3	19-208	Nut - 3/8 Push	63	19-111	Nut - 3/8-16 Center Lock Jam
4	26-143	Spacer - No. 10 I.D. x 5/16	64	28-129	Pin - Roll 5/32 x 3/4
5	20-317	Bolt - 10-24 x 3/4 Carriage	65	10-244	Guard - Chain
6	4-238	Handle - Clutch	66	135-63	Sprocket - Drive
7	18-42	Bolt - 1/4-20 x 1-1/4	67	98-14	Ring - Retaining
8	4-234	Handle - Folding	68	28-50	Pin - Spring
9	8-113	Control - Throttle	69	79-186	Arm - Front, Left
10	19-117	Nut - Hex 1/4-20 Locking	70	2-243	Housing
11	18-44	Bolt - 1/4-20 x 1-3/4	71	22-147	Baffle
12	76-70	Spring	72	7-365	Bracket - Yoke, R.H.
13	7-437	Bracket Assy., - Height Adj.	73	26-158	Spacer - Transmission Housing - 5/16"
14	46-53	Knob - Throttle Control	74	26-157	Spacer - Transmission Housing - 1/4"
15	108-82	Lever - Height Adj.	75	62-34	Rivet
16	20-156	Bolt - Engine	76	17-143	Clip
17	47-592	Cable - Height Adj.	77	10-234	Trailguard
18	21-44	Washer	78	11-177	Bushing - Drive Shaft
19	5-19	Knob - Height Adj.	79	62-41	Rivet
20	20-287	Screw - Shroud	80	7-456	Bracket - Axle Support
21	130-18	Shroud	81	43-398	Support - Axle
22	18-131	Bolt - Handle	82	28-16	Pin - Cotter 3/32 x 3/4
23	21-191	Washer - Curved	83	21-33	Washer - 3/8 Flat
24	21-197	Washer - Lock	84	65-86	Axle Assembly - Rear
25	19-183	Nut - Wing	85	20-282	Screw - 10-24 x 1/2
26	6-76	Yoke	86	11-117	Bearing - Wheel
27	17-2	Clamp - Cable	87	102-180	Shaft - Drive
28	20-195	Screw - Casing	88	134-16	Link - Height Adj.
29	17-80	Clamp - Casing	89	11-109	Bearing - Wheel
30	108-89	Release Arm - Clutch	90	3-196	Wheel Assy. - Rear
31	7-480	Bracket Assembly - Cable	91	21-199	Washer
32	20-339	Eyebolt	92	20-303	Bolt - Hex
33	20-186	Bolt - Thread Forming	93	26-153	Spacer - Wheel
34	10-245	Cover - Transmission	94	11-176	Bearing - Drive Shaft
35	20-294	Bolt - Hex	95	10-238	Cover - Gear
36	128-56	Clutch Assembly	96	39-60	Disc - Ratchet
37	21-44	Washer - Flat	97	139-6	Cam - Ratchet
38	21-190	Washer - Drive Shaft	98	76-145	Spring - Ratchet
39	11-174	Bearing - Transmission	99	101-94	Gear - Drive
40	43-402	Brace - Axle	100	11-175	Bushing - Axle
41	19-1	Nut - 10-24 Hex Keps	101	26-151	Spacer - Axle
42	110-62	Chain - No. 48, 52 Rollers	102	65-76	Axle Weldment
43	76-148	Spring - Chain Tension	103	22-152	Baffle
44	28-2	Pin - Roll	104	3-135	Wheel Assembly
45	89-34	Hub Cap	105	26-147	Spacer - Wheel
46	102-183	Shaft - Transmission	106	20-313	Bolt - Hex 3/8-16 x 2-1/4
47	7-476	Bracket - Release Arm Pivot	107	16-1	Key
48	21-138	Washer - Spring	108	15-36	Adapter - Blade
49	135-62	Sprocket - Drive	109	1-139	Blade - Mulcher
50	110-37	Chain - No. 48, 30 Rollers	110	26-97	Spacer - Adapter
51	54-326	Decal - "Place Foot...."	111	21-18	Washer - Blade
52	28-78	Pin - Roll	112	18-36	Bolt - Blade
53	18-1	Bolt - 1/4-20 x 5/8	113	18-110	Bolt - 1/4-20 x 1/2
54	76-135	Spring - Chain Tension	114	19-2	Nut - 1/4-20 Keps
55	28-110	Pin - Roll	115	43-395	Panel Brace
56	2-261	Housing Assy. - Transmission	116	26-165	Spacer - Shoulder
57	105-82	Pulley - Cable	117	28-23	Pin - Roll
58	18-41	Bolt - 5/16-18 x 3/4	118	76-149	Spring - Release Arm
59	7-364	Bracket - Yoke, L.H.	119	54-542	Decal - Danger
60	19-118	Nut - 5/16-18			