



PARTS LIST FOR MODEL 11-2260

Ref. No.	Part No.	Description	Ref. No.	Part No.	Description
1	4-228AS	Handle Assembly - Clutch	62	28-131	Pin - Spring 5/32 x 1
2	19-141	Nut 10-24	63	19-1	Nut - Hex Keps 10-24
3	21-221	Washer	64	2-239AS	Housing Assembly - Transmission
4	47-582	Cable - Clutch	65	20-186	Bolt - 1/4-20 x 1/2
5	26-143	Spacer	66	20-269	Screw - Hex Washer Hd 10-24 x 3/8
6	20-317	Bolt - Carriage 10-24 x 3/4	67	76-135	Spring - Chain Tension
7	19-208	Nut - Push	68	62-44	Rivet
8	18-44	Bolt - Hex Hd 1/4-20 x 1-3/4	69	112-53	Strap - Trailguard
9	18-42	Bolt - Hex Hd 1/4-20 x 1-1/4	70	10-241	Trailguard
10	19-117	Nut - 1/4-20	71	28-130	Pin - Spring 3/16 x 1
11	4-226	Handle	72	135-24	Sprocket - Drive
12	8-110	Control - Throttle	73	134-17	Link
13	18-18	Bolt - Hex Hd 1/4-20 x 1-1/2	74	2-235	Housing
14	7-417AS	Bracket Assembly - Height Adj.	75	89-34	Hub Cap
15	108-82	Lever - Height Adj.	76	20-303	Bolt - Hex Hd 3/8-16 x 2-3/4
16	76-70	Spring - Chute	77	26-153	Spacer - Wheel
17	47-577	Cable - Height Adj.	78	3-196AS	Wheel Assembly - Rear
18	5-19	Grip - Handle	79	11-109	Bearing - Wheel
19	18-131	Bolt - Curved Hd 5/16-18 x 2	80	28-16	Pin - Cotter 3/32 x 3/4
20	21-191	Washer - Curved	81	101-94	Gear - Drive
21	21-197	Washer	82	76-137	Spring - Ratchet
22	46-52	Knob - Handle	83	139-6	Cam - Ratchet
23	6-72	Yoke	84	39-60	Disc - Ratchet
24	17-2	Clamp - Cable	85	10-238	Cover - Gear
25	17-107	Clip - Hairpin	86	11-176	Bearing - Drive Shaft
26	28-124	Hairpin	87	102-166	Shaft - Drive
27	103-30	Latch - Door	88	65-77AS	Axle Assembly - Rear
28	76-129	Spring - Door Latch	89	11-177	Bushing - Drive Shaft
29	82-159	Rod - Door Latch	90	17-147	Clip - Axle
30	7-438	Bracket - Chute	91	20-313	Bolt - Hex Hd 3/8-16 x 2-1/4
31	20-277	Screw - Hex Washer Hd 10-24 x 5/8	92	26-147	Spacer - Wheel
32	20-67	Screw - Hex Hd 3/8-16 x 1	93	3-135AS	Wheel Assembly - Front
33	28-110	Pin - Roll 7/32 x 3/4	94	11-117	Bearing - Wheel
34	105-82	Pulley - Cable	95	20-321	Bolt - 3/8-16 x 1-1/8
35	7-420AS	Bracket Assembly - Right Yoke	96	65-71AS	Axle Assembly - Front
36	7-436AS	Bracket Assembly - Left Yoke	97	19-111	Nut - 3/8-16
37	154-6AS	Door Assembly	98	17-146	Clip - Axle
38	4-209	Handle - Door	99	28-16	Pin - Cotter 3/32 x 3/4
39	28-50	Pin - Roll 3/16 x 1	100	16-1	Key - Woodruff
40	79-181AS	Arm Assembly - Door	101	15-21AS	Blade Adapter Assembly
41	76-128	Spring - Torsion	102	1-111	Blade - 22"
42	76-127	Spring - Compression	103	26-97	Spacer - Blade Adapter
43	20-327	Screw - Hex Washer 10-24 x 7/8	104	21-18	Washer - Lock
44	82-157AS	Rod Assembly - Door	105	18-36	Bolt - Hex Hd 3/8-24 x 1
45	20-282	Screw - Hex Washer Hd 10-24 x 1/2	106	17-80	Clamp - Casing
46	43-394	Support - Hinge Pin	107	20-195	Screw - Casing Clamp
47	28-128	Pin - Hinge	108	130-18	Shroud
48	75-7AS	Hinge Assembly - Clutch	109	20-287	Screw - Hex, 8 x 3/8
49	6-46	Yoke - Clutch	110	10-239	Cover - Transmission
50	21-190	Washer - Drive Shaft	111	98-14	Ring - Retaining
51	11-174	Bearing	112	25-101	Tube - Bag
52	26-152	Spacer	113	30-0450	Replacement Bag
53	28-2	Pin - Roll 5/32 x 1	114	99-63AS	Frame Assembly - Catcher
54	16-30	Key - Clutch	115	19-51	Nut - Hex 10-24
55	102-165	Shaft - Clutch	116	19-146	Nut - Top Lock
56	39-38	Disc - Clutch	117	21-33	Washer - Flat
57	135-23	Sprocket	118	21-199	Washer
58	110-60	Chain - No. 48, 51 Rollers	119	76-136	Spring - Clutch
59	21-138	Washer - Spring	120	54-406	Decal - Cutting Height
60	110-37	Chain - No. 48, 30 Rollers	121	54-432	Decal - Rear Door
61	135-60	Sprocket - Drive			