


11-2262
50525A



PARTS LIST FOR MODELS 11-2262 & 50525A

Ref. No.	Part No.	Description	Ref. No.	Part No.	Description
1	4-227	Handle Assy - Clutch	61	135-63	Sprocket - Drive
2	19-141	Nut 10-24	62	28-78	Pin - Roll 3/32 x 1
3	21-44	Washer	63	19-1	Nut - Hex Keps 10-24
4	47-596	Cable - Clutch	64	2-262	Housing Assy - Transmission
5	26-143	Spacer	65	20-186	Bolt - 1/4-20 x 1/2
6	20-317	Bolt - Carriage 10-24 x 3/4	66	28-16	Pin - Cotter
7	19-208	Nut - Push	67	76-135	Spring - Chain Tension
8	18-44	Bolt - Hex Hd 1/4-20 x 1-3/4	68	62-44	Rivet
9	18-42	Bolt - Hex Hd 1/4-20 x 1-1/4	69	28-23	Pin - Roll
10	19-117	Nut - 1/4-20	70	10-241	Trailguard
11	4-226	Handle	71	54-505	Decal - Rear Door
12	8-110	Control - Throttle	72	135-62	Sprocket - Drive
13	18-18	Bolt - Hex Hd 1/4-20 x 1-1/2	73	134-17	Link
14	7-417	Bracket Assembly - Height Adj.	74	2-235	Housing
15	108-82	Lever - Height Adj.	75	89-34	Hub Cap
16	76-70	Spring -	76	20-303	Bolt - Hex Hd 3/8-16 x 2-3/4
17	47-577	Cable - Height Adj.	77	26-153	Spacer - Wheel
18	5-19	Grip - Handle	78	3-196	Wheel Assy - Rear
19	18-131	Bolt - Curved Hd 5/16-18 x 2	79	11-109	Bearing - Wheel
20	21-191	Washer - Curved	80	54-406	Decal - Cutting Height
21	21-197	Washer	81	101-94	Gear - Drive
22	46-52	Knob - Handle	82	76-145	Spring - Ratchet
23	6-72	Yoke	83	139-6	Cam - Ratchet
24	17-2	Clamp - Cable	84	39-60	Disc - Ratchet
25	7-489	Bracket Assy - Cable Mounting	85	10-238	Cover - Gear
26	28-124	Hairpin	86	11-176	Bearing - Drive Shaft
27	103-30	Latch - Door	87	102-166	Shaft - Drive
28	76-129	Spring - Door Latch	88	65-77	Axle Assy - Rear
29	82-159	Rod - Door Latch	89	11-177	Bushing - Drive Shaft
30	7-438	Bracket - Chute	90	17-147	Clip - Axle
31	20-277	Screw - Hex Washer Hd 10-24 x 5/8	91	20-313	Bolt - Hex Hd 3/8-16 x 2-1/4
32	20-67	Screw - Hex Hd 3/8-16 x 1	92	26-147	Spacer - Wheel
33	128-68	Clutch Assy	93	3-135	Wheel Assy - Front
34	105-82	Pulley - Cable	94	11-117	Bearing - Wheel
35	7-420	Bracket Assy - Right Yoke	95	20-321	Bolt - 3/8-16 x 1-1/8
36	7-422	Bracket Assy - Left Yoke	96	65-71	Axle Assy - Front
37	154-6	Door Assy	97	19-111	Nut - 3/8-16
38	4-209	Handle - Door	98	17-146	Clip - Axle
39	28-50	Pin - Roll 3/16 x 1	99	28-139	Pin - Roll 7/32 x 1
40	79-181	Arm Assy - Door	100	16-1	Key - Woodruff
41	76-128	Spring - Torsion	101	15-21	Blade Adapter Assy
42	76-127	Spring - Compression	102	1-111	Blade - 22"
43	20-327	Screw - Hex Washer 10-24 x 7/8	103	26-97	Spacer - Blade Adapter
44	82-157	Rod Assy - Door	104	21-18	Washer - Lock
45	20-282	Screw - Hex Washer Hd 10-24 x 1/2	105	18-36	Bolt - Hex Hd 3/8-24 x 1
46	62-34	Pop Rivet	106	17-80	Clamp - Casing
47	18-41	Bolt - Hex Cap	107	20-195	Screw - Casing Clamp
48	108-90	Release Arm - Clutch, Plated Tip	108	130-18	Shroud
49	7-476	Bracket - Release Arm Pivot	109	20-287	Screw - Hex 8 x 3/8
50	21-190	Washer - Drive Shaft	110	10-251	Cover - Transmission
51	11-174	Bearing	111	98-14	Ring - Retaining
52	19-118	Nut - 5/16-18	112	25-101	Tube - Bag
53	28-2	Pin - Roll 5/32 x 1	113	30-0450	Replacement Bag
54	76-163	Spring - Release Arm	114	99-63	Frame Assy - Catcher
55	102-186	Shaft - Clutch	115	21-199	Washer
56	26-165	Spacer - Shoulder	116	19-146	Nut - Top Lock
57	20-339	Eyebolt	117	21-33	Washer - Flat
58	110-60	Chain - No. 48, 51 Rollers			
59	21-138	Washer - Spring			
60	110-37	Chain - No. 48, 30 Rollers			