



PARTS LIST FOR MODELS 11-ASP223 & 12-AESP223

Ref. No.	Part No.	Description	Qty.	Ref. No.	Part No.	Description	Qty.
1	46-43	Knob - Throttle & Gear Shift	2	61	22-74	Baffle - Rear	1
2	43-367	Panel - Control	1	62	18-71	Bolt	2
3	130-21	Shroud	1	63	76-71	Spring - Q.W.A.	2
5	20-279	Screw - Shroud	4	64	137-9	Tip - Q.W.A. Spring	4
6	4-176	Handle	1	65	79-121	Arm - Q.W.A.	2
7	8-57	Control - Throttle	1	66	130-20	Chute	1
8	8-88	Control - Clutch	1	67	18-127	Bolt - Carriage	3
9	18-131	Bolt - C-Head	2	68	74-22	Seal - Strip	1
10	6-62	Yoke	1	69	18-101	Bolt - Axle, Front	2
11	28-50	Pin - Roll	1	70	3-134	Wheel Assy	2
12	135-24	Sprocket	1	71	101-71	Gear - Drive	2
13	98-62	Ring - Retaining	2	72	11-123	Bearing	2
14	135-25	Sprocket - Idler	2	73	76-81	Spring	2
15	17-2	Clip - Cable	2	74	79-135	Arm - Q.W.A.	2
16	21-191	Washer - Curved	2	75	102-136	Shaft - Drive	1
17	46-44	Knob	2	76	20-186	Screw	9
18	7-294	Bracket Assy - Yoke L.H.	1	77	11-109	Bearing - Sleeve	2
19	20-145	Screw	8	78	10-156	Cover - Gear	2
20	11-106	Bushing - Spacer	2	79	12-153	Plate - Q.W.A.	2
21	110-36	Chain - No. 48, 58 Rollers	1	80	19-164	Nut - Eslock	2
22	110-39	Master Link - No. 48	1	81	20-156	Screw	3
23	110-40	Half Link - No. 48	1	82	2-151	Housing - Mower	1
24	108-45	Idler - Lever Assy	1	83	22-90	Baffle - Front	1
25	10-187	Guard - Trailing	1	84	7-300	Bracket Assy - Q.W.A., R.H.	1
26	124-6	Button - Drag Plate	2	85	7-301	Bracket Assy - Q.W.A., L.H.	1
27	10-164	Cover Assy - Chain	1	86	1-110	Blade	1
28	43-326	Brace - Deck Assy	1	87	15-21	Adapter - Blade	1
29	17-107	Clip - Yoke	2	88	16-1	Key - Engine Shaft	1
30	110-37	Chain - No. 48, 30 Rollers	1	89	21-190	Washer	2
31	26-80	Spacer - Sprocket	1	90	28-4	Pin - Roll	3
32	110-38	Chain - No. 48, 32 Rollers	1	91	16-30	Key - Clutch	1
33	135-23	Sprocket	4	92	39-38	Disc - Clutch	1
34	76-96	Spring	1	93	75-6	Hinge - Clutch	1
35	20-269	Screw	4	94	18-36	Bolt - Blade	1
36	21-90	Washer - Lock	1	95	21-18	Washer	1
37	100-3	Fitting - Grease	1	96	26-97	Spacer - Blade Adapter	1
38	102-107	Shaft - Idler	1	97	6-46	Yoke - Clutch	1
39	7-302	Bracket Assy - Idler	1	98	82-109	Rod - Clutch Pivot	1
40	76-80	Spring - Chain Tension	1	99	2-165	Housing - Clutch	1
41	19-117	Nut	3	100	12-164	Plate - Shift Wire	1
42	21-14	Washer	1	101	20-267	Screw - SMS	1
43	18-1	Bolt	1	102	10-162	Cover - Cleanout	1
44	20-240	Screw	8	114	19-2	Nut - Keps	1
45	7-264	Bracket Assy - Q.W.A., R.R.	1	115	89-34	Hub Cap	4
46	7-240	Bracket Assy Q.W.A., L.R.	1				
47	19-1	Nut - Hex Keps	3				
48	17-123	Clamp	3				
49	20-283	Screw (12-AESP223)	1				
50	20-282	Screw (12-AESP req. 2)	3				
51	18-125	Bolt - Rear Wheel	2	103	16-27	Key - Ignition	1
52	3-135	Wheel Assy	2	104	19-148	Nut - Face	1
53	11-117	Bearing - Sleeve	2	105	43-368	Panel - Control	1
54	21-113	Washer	4	106	19-149	Nut - Lock	1
55	12-145	Plate - Q.W.A.	2	107	9-43	Switch - Lock	1
56	19-111	Nut	2	108	47-515	Harness	1
57	19-147	Nut - Q.W.A.	8	109	17-111	Clip - Harness	1
58	26-105	Spacer (12-AESP223)	1	110	47-516	Charge Pack	1
59	19-143	Nut	4	111	17-124	Clip - Battery	1
60	19-141	Nut	2	112	12-158	Battery Plate	1
				113	143-7	Battery	1

ELECTRIC START ONLY