



PARTS LIST FOR MODELS 12-5021, 50080, 50496 & T88-4

Ref. No.	Part No.	Description	Ref. No.	Part No.	Description
1	46-36	Knob -- Throttle	69	20-145	Bolt -- Hex Hd
2	20-282	Screw -- Hex Hd	70	19-117	Nut -- Hex
3	4-169	Handle Bar Assy	71	18-49	Bolt -- Washer Hd
4	5-5	Grip -- Handle	72	28-77	Cotter -- Hairpin
5	5-26	Grip -- Lever	73	82-141	Rod -- Lower
6	8-86	Throttle Control	74	19-136	Nut -- L.H.
7	19-118	Nut -- Hex	75	19-83	Turnbuckle 5/16
8	19-111	Nut -- Jam	76	122-74	Belt Guide Assy
9	56-18	Tip -- Lever	77	98-74	Belt Retainer Assy
10	108-71	Lever -- Wheel Adj.	78	18-38	Bolt -- Hex Hd
11	21-33	Washer	79	68-22	Hood -- Tines
12	79-158	Arm -- Wheel Adj.	80	43-371	Main Support Assy
13	18-41	Bolt -- Hex Hd	81	19-57	Nut
14	19-1	Nut -- Hex	82	79-155	Arm -- Pivot
15	17-131	Clip -- Cable	83	19-119	Nut -- Hex
16	41-174	Panel Assy	84	122-72	Belt Guard
17	22-106	Plate -- Lockout	85	3-167	Wheel -- R.H.
18	21-138	Washer -- Spring	86	21-159	Washer -- Flat
19	18-60	Bolt -- Shoulder	87	65-65	Axle Assy
20	19-139	Nut -- Hex	88	20-45	Bolt -- Shoulder
21	21-113	Washer -- Curved	89	3-166	Wheel -- L.H.
22	108-67	Lever -- Hi-Speed	90	28-26	Cotter Pin
23	20-280	Screw -- Round Hd	91	20-189	Bolt -- Hex Hd
24	46-40	Knob -- Plain	92	74-14	Oil Seal
25	108-69	Lever -- Engagement	93	11-17	Bearing -- Sleeve
26	46-41	Knob -- Threaded	94	16-3	Woodruff Key
27	28-20	Pin -- Roll	95	20-157	Bolt -- Hex Hd
28	21-62	Washer -- Flat	96	2-196	Housing -- Gear
29	35-8	Stud -- Lever	97	11-18	Bearing -- Needle
30	76-108	Spring -- Lever	98	74-15	Oil Seal
31	26-110	Spacer -- Lever	99	59-15	Shield -- Bearing
32	21-13	Washer -- Flat	100	89-43	Hub Assy -- Inner
33	19-2	Nut -- Hex	101	84-25	Tine -- Slasher R.H.
34	18-132	Bolt -- Hex	102	84-26	Tine -- Slasher L.H.
35	76-105	Spring -- Rod	103	84-51	Inner Tine Assy R.H. & L.H.
36	28-7	Cotter -- Hairpin	104	89-42	Hub Assy -- Outer
37	7-370	Drag Bracket Assy	105	20-67	Bolt -- Hex Hd
38	136-11	Drag Bar	106	84-52	Outer Tine Assy R.H.
39	10-198	Cover -- Main Support	107	10-122	Plate -- End Cover
40	20-131	Screw -- Hex Hd	108	98-49	Retaining Ring
41	20-46	Bolt -- Hex Hd.	109	26-82	Spacer -- End-Worm
42	21-192	Washer -- Flat	110	11-94	Bearing -- Ball
43	105-87	Pulley -- Idler	111	26-81	Spacer -- Center-Worm
44	79-110	Arm -- Forward-Lo	112	101-58	Worm
45	76-39	Spring -- Extension	113	28-23	Roll Pin
46	79-154	Arm -- Forward-Hi	114	28-102	Roll Pin
47	76-96	Spring -- Idler Arm	115	102-89	Shaft -- Worm
48	18-88	Bolt	116	114-5	Plug -- Gear Box
49	28-16	Cotter Pin	117	98-7	Retaining Ring
50	28-6	Clevis Pin	118	102-88	Shaft -- Output
51	79-151	Arm -- Reverse	119	101-57	Worm Gear
52	26-113	Spacer -- Idler Arm	120	98-6	"O" Ring
53	27-105	Plate -- Idler Arm	121	10-121	Cover -- Gear Housing
54	105-78	Pulley -- 3 Groove	122	10-123	Housing Cover Assy
55	107-37	Belt -- V	123	84-53	Outer Tine Assy L.H.
56	105-73	Pulley -- 2 Groove	124	2-197	Gear Housing Assy
57	16-36	Key -- Square	125	19-141	Nut -- Hex
58	20-255	Set Screw	128	28-111	Clevis Pin
59	105-80	Pulley -- Reverse			
60	16-9	Woodruff Key			
61	134-14	Connecting Link			
62	7-349	Bracket -- Handle L.H.			
63	7-350	Bracket -- Handle R.H.			
64	47-545	Cable Assy			
65	82-134	Rod -- Upper			
66	19-24	Nut -- R.H.			
67	122-45	Guide -- Cable			
68	76-111	Spring -- Cable			

OPTIONAL ACCESSORIES

126	23-54	Furrowing Kit
127	84-46	Tine Extension Kit