

DROP SPREADER MODEL 45-0279

Item No.	Part No.	Description	Item No.	Part No.	Description
1	63721	Flow Plate Assembly	15	47255	Vinyl Cap (2)
2	47259	Agitator Blade (2)	16	47256	Vinyl Cap
3	47260	Upper Control Rod	17	47257	Control Gauge
4	47261	Lower Control Rod	18	24455	Clamp, Control Rod (2)
5	47263	Leg Tube, L.H.	19	47183	Handle Grip (2)
6	47262	Leg Tube, R.H.	20	47316	Carriage Bolt, 1/4-20 x 2-1/4"
7	47264	Axle	21	47272	Flat Washer, 1" OD (4)
8	47265	Wheel (2)	22	47188	Slotted Head Bolt, #10-32 x 1-3/4" (3)
9	47266	Bearing (2)	23	47156	Slotted Head Bolt, #10-32 x 1-1/2" (4)
10	47267	Handle Tube (2)	24	43346	Slotted Head Bolt, #10-32 x 5/8"
11	47155	Bushing (2)	25	43662	Hex Nut, #10-32 Threads (8)
12	44663	Push Nut/Hub Cap (2)	26	43088	Flat Washer, 1/4"
13	47159	Slotted Head Bolt, #8 x 1/4" (8)	27	47141	Wing Nut, 1/4-20 Threads
14	47269	Hopper	28	47110	Wing Nut, Self Threading
				47270	Owner's Manual

