

MODEL 45-0284 PARTS LIST

Item No.	Part No.	Description	Item No.	Part No.	Description
1	44663	Push Nut/Hub Cap (2)	16	47136	Clip, Gear Retainer
2	47109	Flow Slide	17	47387	Hitch/Control Tube
3	43878	Agitator Wire	18	47384	Hitch Tube, R.H.
4	47112	Screw, #10-16 x 1/2" (3)	19	47383	Hitch Tube, L.H.
5	63688	Control Gauge Assembly	20	47386	Leg Tube, R.H.
6	24441	Control Gauge Clamp	21	47385	Leg Tube, L.H.
7	47110	Wing Nut, Self Threading	22	47137	Handle Tube
8	47118	Control Cable Assembly	23	46000	Carriage Bolt, 1/4-20 x 1-1/2" (3)
9	47273	Wheel (2)	24	47113	Washer, Flat .22" x .78" (2)
10	63690	Axle/Impeller Assembly	25	47141	Wing Nut, 1/4-20
11	47124	Impeller (Included in #63690)	26	47186	Slot Head Bolt, #10-32 x 1-1/2"
12	47126	Screw, Hex Head #10-32 x 3/8"	27	43662	Hex Nut (SEMS) #10-32
13	47155	Bushing (2)	28	45091	Clevis Pin, 3/8" x 1"
14	47134	Pin, Hair Cotter	29	43081	Washer, 5/16"
15	47135	Washer, 17/32" x 7/8"	30	47139	Hopper

